

PROGRAMING THE ICOM ICT2H SPORT

Push the A V key so MR does not appear in the display.

Enter the 6-digit frequency the radio will be receiving on.

Push the DUP key for the proper offset or simplex.

The choices in the display are –DUP, DUP (which is actually +DUP)

Or nothing in the display which is Simplex.

If a subaudible tone is required to access the repeater, push the C T key until a single T appears next to the DUP indicator in the display.

Push and hold (1 second) the A V key until the menu display appears

Use the ◀ key to get to the RP menu.

Use the ▲▼ to get to the subaudible tone frequency you want.

Momentarily push the A V key and your desired receiving frequency should appear.

Momentarily push the B M key. MR and the channel number below it should be flashing in the display.

Use the ▲▼ keys until the desired channel where you wish to store this information is displayed.

Hold the B M key (1 second) until you hear 2 beeps.

The display should show the selected frequency without the MR showing.

Push the A V key and the radio is back in memory mode with MR in the display.

Using the ▲▼ keys you can scroll through the memory channels.