

IC V82

SHORTCUT INSTRUCTIONS

If necessary, reset the CPU on the radio. With the power off, Push and Hold the D/clr and the MONI button, then hold the PWR button for 1 second. Release all keys.

Be sure you are in the VFO mode. Do this by pushing the D key. There should be NO MR showing on the radio.

Key in a frequency using the keypad.

If an offset is required, we will enter it now. Normally, the radio will go to the proper offset, but there may be times it has to be changed. Push the A/func key, then the 4 key. Do this as many times as necessary until the desired offset is shown. If nothing shows, that indicates you will be on SIMPLEX.

If a subaudible tone (PL) is necessary, push the A key then the 1 key until a musical note appears in the display.

Push A then 8 to enter the SET MODE.

Push the UP or DOWN keys until r t appears in the display.

Using the volume control knob, rotate it until the desired PL tone frequency is displayed.

Push the */ent key to set the information.

At this point the information is SET but is NOT in memory.

To place the information into a memory channel, Push the A then the C keys.

The MR box should be flashing on the display.

Using the UP and DOWN keys, select a memory channel where you want the information to be stored. Push the A key and then HOLD the C key for 1 second. When you hear 3 beeps, the information has been entered into memory.

By pushing the C key, you enter the Memory Recall mode and are able to scroll through the memories with the UP and DOWN keys.