

ICOM IC-V8000

REPEATER STORAGE

Press VFO (MIC)

Press up or down to get freq

Press 'FUNC', then 'TONE' (7)

Press 'SET B' several times

until musical note appears

Press 'CLR A' to exit, press PTT

Press :FUNC" then" CLR A"

Select memory channel

Press "FUNC" then" CLR A"

for 1 second,

3 beeps will sound when done

Press PTT

POWER SETTINGS (RADIO)

Press (low[dup]) several times

for desired level

RON GREEN KG6RLG

ICOM IC- V8000

SIMPLEX STORAGE

Press VFO (MIC)

Press up or down to get freq

Press 'SET B' several times

until musical note appears

Press 'CLR A' to exit

Select memory channel

Press 'FUNC' then 'CLR A'

for 1 second

3 beeps will sound when done

Press PTT

POWER SETTINGS (MIC)

Press '4 for high (75w)

Press '5' for medium (25w)

Press '6' for low (5w)

DELETE FREQS

Select freq, press (MW/S.MW)

Press (MW/S.MW)again for 1 sec

3 beeps will sound