

IC -T2H

There are two modes worth knowing about:

VFO: (no MR icon) press **aV**

Memory: (little **MR** icon) press **C**

You want to be in memory mode to switch between saved frequencies

Set Frequency

Push **aV**; enter 6-digit frequency;

Set Offset

Push **DUP**

(enough times to choose - or +)

Set PL (subaudible tone)

Push **CT to activate subaudible tone**;

A **T** appears

Press **aV** for 1 second.

Push **◀** until **RP** appears

Push **▼** or **▲** to select offset frequency

Press **aV** to set offset frequency

Set Memory (#)

Push **bM**; [MR] blinks

Push **▼** or **▲** to choose memory channel

Push AND HOLD **bM** for 1 sec

Press **aV** to toggle/restore **MR** icon

Pushing **▼** or **▲** cycles between saved frequencies