

YAESU FT-60

REPEATER FREQS

press V/M, select frequency
press F/W, press 1
rotate dial to TONE, press PTT
press F/W then 2, rotate dial
to desired tone freq
press F/W 1 second, press F/W

KEYBOARD LOCK

press and hold "6"

WIRES

press "0" (atomic symbol)

POWER CHANGE

press F/W, press 3
rotate dial to desired level

REVERSE

press "C"

RON GREEN KG6RLG

YAESU FT-60

SIMPLEX FREQS

press V/M, select frequency
press F/W, 1 second
press F/W to store
press V/M to memory

SIMPLEX W/ Code

press V/M, select frequency
press F/W, press 1, rotate
dial to TONE SQL, press PTT
press F/W, press 2
rotate dial to desired freq
press F/W 1 second
press F/W again, press PTT

DELETE FREQS

press V/M, press F/W 1 sec
press H/M R/V for a moment