

FT-897 Tuning Instructions

- 1- Make sure you are in FM mode.
Set the frequency on the screen. For a repeater, continue. For a simplex freq, go to Step 9.
- 2- Turn SQL full counterclockwise.
- 3- Press [F] momentarily to go to MFd.
- 4- Press [A]RPT to set repeater duplex on + or -.
- 5- Go to MFe
- 6- Press [A]TON for 1 second - goes to Menu 83 - turn dial to access chosen tone.
- 7- Press [F] for 1 second.
- 8- Press [A]TON to activate encoder till TEN is on display.
- 9- Press [F] momentarily to go to MFb.
- 10- Press [A]MW to check which was last channel recorded.
- 11- Turn Mem/VFO to next open memory channel.
- 12- Press [A]MW for 1 second to save into channel chosen.
- 13- Recall memory channel chosen.
- 14- Go to MFb - press [C]TAG for 1 second - goes to Menu 56.
- 15- Press [MEM/VFO] to start entering label.
- 16- Turn dial to start entering alpha characters.
- 17- Press [F] for 1 second to save and exit.
- 18- Press [C]TAG momentarily to toggle freq. and label.

Compliments of Frank K6FCW